

# Helium–Neon Laser


A. Simankovich   D. Dedkov

Moscow Institute of Physics and Technology


# Abstract

TODO


# Elementary processes



a) Absorption



b) Stimulated Emission



c) Spontaneous Emission

$$\left( \frac{dN_0}{dt} \right)_{\text{abs}} = -B_{01}N_0\rho(\omega)$$

$$\left( \frac{dN_0}{dt} \right)_{\text{stim}} = B_{10}N_1\rho(\omega)$$

$$\left( \frac{dN_0}{dt} \right)_{\text{spont}} = -A_{10}N_1$$

Einstein coefficients are the same  $B_{01} = B_{10} = B$

phase, direction and frequency of emitted and external photons are identical.

photons radiate independently in all directions.  $\frac{dN_0}{dt}$  **does not** depend on  $\rho(\omega)$ .

Where  $\rho(\omega)$  – spectral energy density of the isotropic radiation field at the frequency of the transition.

# Gain




Figure: General laser scheme

Beer–Lambert–Bouguer law states that intensity of light  $I(x)$  changes:

$$I(x) = I_0 \exp(\gamma x),$$

where  $\gamma$  – medium gain coefficient. With length  $L$  gain per period is called **laser gain**:

$$G = \exp(2\gamma L).$$

## Population inversion

The fact that the number of spontaneously emitted photons does not depend on  $\rho(\omega)$  gives us a reason to neglect  $\left(\frac{dN_0}{dt}\right)_{\text{spon}}$  term. Number of photons emitted at a time  $dt$ :

$$\frac{dN}{dt} = \left(\frac{dN_0}{dt}\right)_{\text{abs}} + \left(\frac{dN_0}{dt}\right)_{\text{stim}} = B(N_1 - N_0)\rho(\omega) \quad (1)$$


Therefore:

$$\gamma = \frac{dI}{I} = \frac{dN \cdot \hbar\omega}{\rho(\omega)} = B \frac{\hbar\omega}{v} (N_1 - N_0), \quad (2)$$

where  $v = \frac{c}{n}$  – speed of light inside medium.

$\gamma$  is positive if  $N_1 > N_0$ . This laser principle is called  
**population inversion**

## Generation spectrum



Generation spectrum of He-Ne laser is defined by three factors: natural broadening, Doppler broadening and loss rate.

$$\omega_n \approx 2\pi/\tau_n \Rightarrow \nu_n \approx 10^8 \text{ Hz},$$

$\tau_n \approx 10^{-8} \text{ s}$  – lifetime of 630 nm Ne transition.

$$\omega_D \approx \omega \frac{v_T}{c}, \approx 1.5 \cdot 10^9 \text{ Hz}$$

$v_T$  – thermal motion velocity (assuming  $T = 400 \text{ K}$ ).

And loss rate reduces spectrum even further:

$$2\gamma L > -\ln K - \ln r_1 r_2,$$

$r_1, r_2$  – mirrors reflectance,  $K$  – part of remaining intensity.

# Longitudinal Modes

Mode – stationary wave pattern in resonator with particular frequency and spatial distribution.




Figure: Longitudinal modes


Most of the energy in resonator cavity is concentrated in standing waves. Therefore, condition on  $TEM_{00q}$  modes goes as follows:

$$L = q \frac{\lambda}{2} \Rightarrow \omega_q = q \frac{\pi c}{L} \approx 2\pi \cdot 100 \text{ MHz}, \quad q \in \mathcal{N},$$

$$L \approx 1.5 \text{ m.}$$

## Modes spectrum

Every  $TEM_{00q}$  gives narrow spectrum  $\omega_q \pm \Delta\Omega_{TEM}$ .



Taking into account that

$$\Delta\Omega_{TEM} \approx \frac{\omega_q}{Q},$$


$Q$  – Q-factor, and using common parameters of He-Ne laser we get:

$$\Omega_{TEM} \approx 2\pi \cdot 10^6 \text{ Hz.}$$



# Singlemode and multimode

Applying modes spectrum to generation spectrum we get:





In generation spectrum, created by medium, resonator spectrum cuts off a few frequencies.

Estimating maximal number of modes:

$$N_m = \omega_D / \omega_n = 15.$$


# Polarization of Laser Emission



To remove reflections from laser's windows the Brewster's angle properties can be used:

$$r_p = \frac{E_r}{E_i} = \frac{n_2 \cos \theta_i - n_1 \cos \theta_t}{n_2 \cos \theta_i + n_1 \cos \theta_t} \bigg|_{\theta_i = \theta_B} = 0$$

# Malus' law



**Figure:** Malus' law (here  $\theta_i = \theta_1 - \theta_0$ )


To study the laser's polarization, polaroid and Malus' law is used:

$$I(\theta_i) = I_0 \cos^2 \theta_i,$$

where  $I_0$  is the initial intensity and  $\theta_i$  is the angle between the light's initial polarization direction and the axis of the polarizer.

# Measurements and Results

# Experimental setup




# Experimental Setup



Figure: Photo of laboratory setup

# Laser Gain



**Figure:** Phys-Lab 5.1:  
Oscilloscope, by Palto  
(screenshot)


Photodiodes are connected to the sound card with the ADC. This gives us a direct way to measure intensity.

$$G = \left( \frac{I_1^{\text{on}}}{I_1^{\text{off}}} \right) / \left( \frac{I_2^{\text{on}}}{I_2^{\text{off}}} \right),$$

where  $I_i^j$  – r.m.s. light intensity.  
Series of measurements gives the following result:

$$G = 1.029 \pm 0.006$$

# Laser Polarization



**Figure:** Intensity for different polaroid angles

Interpolating data series in the following form:

$$I(\theta) = A \cos^2 (\Omega\theta + \theta_0),$$

We obtain the following parameters' values:

$$\Omega = 0.998 \pm 0.005$$

$$\theta_0 = (-70 \pm 1)^\circ$$

This demonstrates that Malus's law holds with a great precision.



# Gain

The fact that the number of spontaneously emitted photons does not depend on  $\rho(\omega)$  gives us a reason to neglect  $\left(\frac{dN_0}{dt}\right)_{\text{spon}}$

term. Number of

1. laser tube

laser power supply

4. back mirror

3. front mirror

sound card

2. translucent mirror

6. photodiode 1

11. photodiode 2

7. modulator

screen

10. alignment laser Brewster's angle